


# POCKET FORM ISOLATOR



**72awall**

**PLEASE SEE ALSO:**

**721Q\_a**

**722Q\_a**

**723Q\_a**

**72SQ\_a**

**PLEASE REFER TO PFI SIZING SPREADSHEET FOR  
IDEAL HEIGHTS AVAILABLE FOR THIS UNIT.**

**\* PLEASE BE AWARE THAT FOR PARTIAL POCKETS  
THIS LENGTH INCREASES BY SME'S AS REQUIRED.**