


# POCKET FORM ISOLATOR



**90wall**

**PLEASE SEE ALSO:**

- 901Q**
- 902Q**
- 903Q**
- 90SQ**

**PLEASE REFER TO PFI SIZING SPREADSHEET FOR  
IDEAL HEIGHTS AVAILABLE FOR THIS UNIT.**

**\* PLEASE BE AWARE THAT FOR PARTIAL POCKETS  
THIS LENGTH INCREASES BY SME'S AS REQUIRED.**